


Quickstart Guide

Vector Drive



LED Colour Mix

Function	Colour
Drive	Green
Boost	Orange
Cab Emulation	Blue
Limiter	Invert Flash

To change 'SHAPE' knob function plug in power supply with switch held:

Switch	Function	LED
Bypass	Mid Width	Green
Boost	Fuzz	Red
Both	High Mid	Blue

To enable Cab Emulation, press both switches while bypassed.
Settings are saved upon mode exit and loaded when powered-on.
When switching modes, knob settings only change when a knob is moved.
Reset to factory defaults: rapidly press 'BOOST' 5 times while bypassed.

Warranty & Service
Email: support@z2dsp.com
Website: <http://z2dsp.com>
©Z Squared DSP Pty Limited
ACN 618 834 478
Permission is granted to reproduce this document for personal and educational use.
Commercial reproduction prohibited without permission.